

# Assessing Single Particle Electrocatalysts for Hydrogen Evolution in Neutral Media by Optically Monitoring Reaction Footprints

Louis Godeffroy,<sup>1,\*</sup> Paolo Ciocci,<sup>1</sup> Nathaly Ortiz Peña,<sup>2</sup> Jean-Marc Noël,<sup>1</sup> Damien Alloyeau,<sup>2</sup> Jean-François Lemineur,<sup>1</sup> Frédéric Kanoufi<sup>1</sup>

\*louis.godeffroy@u-paris.fr

<sup>1</sup>Université Paris Cité, CNRS, ITODYS, 75013 Paris, France

<sup>2</sup>Université Paris Cité, CNRS, Laboratoire Matériaux et Phénomènes Quantiques, 75013 Paris, France



### Context

Investigating the electrocatalytic activity of **single nanoparticles (NPs)** is advantageous for at least two reasons:

1. In the absence of carbon and binders, it reveals their **intrinsic activity**.
2. It simplifies the establishment of **structure-activity relationships**.

In this context, **optical microscopies** hold the additional advantage of operating on hundreds of NPs at once. However, they rely on the visualization of markers. The most common ones are **gas nanobubbles (NBs)**, which have the disadvantage of requiring extremely high current densities to nucleate.<sup>[1]</sup> Another option is to visualize the **pH gradient** generated by the reaction of interest, in this case the **hydrogen evolution reaction (HER)**. While this can be done using fluorescent probes, it considerably limits the temporal resolution that can be achieved as substantial accumulation is required to generate a fluorescence microscopy image.

### Principle

Instead, we propose here to visualize the pH gradient through the formation of an insoluble **hydroxide halo**, by refractive index-sensitive optical microscopy.<sup>[2]</sup>

### Case of Ni Nanoparticles

#### Electrochemistry

#### Electrodeposition<sup>[3,4]</sup>

#### Data processing

### COMSOL Model

Explicit simulation of the Ni(OH)<sub>2</sub> halo using the Level Set interface<sup>[5]</sup>

- The charge transfer rate constant  $k_0$  can be quantified for single NPs
- $k_0$  evolves from cycle to cycle

### Size Effect and Versatility

#### 3rd cycle

### Conclusions

- The HER activity of single NPs is evaluated at industrially relevant current densities, without using H<sub>2</sub> NBs as markers.
- The results highlight a size effect and the specific role of Ni(OH)<sub>2</sub> in enhancing the HER activity of Ni and Pt as previously reported.<sup>[6]</sup>
- The methodology is transposable to most electrocatalytic reactions of interest for energy conversion applications, not only to gas evolution reactions, as most of them involve protons (e.g., CO<sub>2</sub>RR or ORR).
- It is also transposable to any microscopy technique able to detect the hydroxide halo *in situ* (e.g., AFM or TEM).

### References

- [1] J.-F. Lemineur *et al.*, *ACS Nano* **2021**, 15, 2, 2643-2653
- [2] L. Godeffroy *et al.*, *Angew. Chem. Int. Ed.* **2023**, 62, 29, e202304950
- [3] L. Godeffroy *et al.*, *Angew. Chem. Int. Ed.* **2021**, 60, 31, 16980-16983
- [4] L. Godeffroy *et al.*, *Small Methods* **2022**, 6, 9, 2200659
- [5] W. Sun *et al.*, *J. Solid State Electrochem.* **2013**, 17, 829-840
- [6] R. Subbaraman *et al.*, *Science* **2011**, 334, 6060, 1256-1260